# SIEMENS





# Thermal actuators



for radiator valves, small valves and zone valves

Operating voltage AC/DC 24 V, 2-position control signal or

PDM (pulse-duration modulation)

- Positioning force 105 N
- For direct mounting with union nut (no tools required)
- Standard version with 1.5 m PVC connecting cable
- Optional connecting cables:
  - 1.5 m, 2.5 m and 4.5 m cables
  - Connecting cables with LED operation indication
  - Non halogen connecting cables
- Supports synchronous running of several actuators in parallel
- Tactile position indication
- Robust construction, quiet operation, no maintenance required
- Optional tamper-proof fitting to prevent dismantling

Use

For water-based control of terminal units, heating and cooling zones

Standard applications (valve closed when actuator de-energized):

- For Siemens small valves types VVP47..., VXP47... and VMP47...
- For retrofitting Siemens small valves 2W..., 3W... und 4W... with AL100 adapter

Special applications (valve open when actuator de-energized):

 For Siemens radiator valves, MiniCombiValves, zone valves and valves from other manufacturers

# Type summary

Туре	Operating voltage	Positioning time at 20 °C	Positioning signal	Connecting cable
STP72E	AC / DC 24 V	180 s	2-position	1.5 m
STP72E/00	AC / DC 24 V	100 5	2-position, PDM 1)	without

<sup>1)</sup> pulse-duration modulation

# Accessories

Adapter type	For valve makes	Adapter type	For valve makes
AV51	Beulco old (M30x1.0)	AV56	Giacomini
AV52	Comap	AV57	Herz
AV53	Danfoss RA-N (RA2000)	AV58	Oventrop old (M30 x 1.0)
AV54	Danfoss RAVL	AV59	Vaillant
AV55	Danfoss RAV	AV60	TA <sup>1)</sup>
		AV61	Markaryd

<sup>1)</sup> No adapter required for type TBV-C

Туре	Connecting cable for STP72E/00		
ASY2L15	1.5 m	Connecting cable 1.5 m	
ASY2L25	2.5 m	Connecting cable 2.5 m	
ASY2L45	4.5 m	Connecting cable 4.5 m	
ASY2L15L	1.5 m	Connecting cable 1.5 m, with LED operation indication	
ASY2L25L	2.5 m	Connecting cable 2.5 m, with LED operation indication	
ASY2L45L	4.5 m	Connecting cable 4.5 m, with LED operation indication	
ASY2L15HF	1.5 m	Connecting cable 1.5 m, non halogen, to VDE 0207-24	
ASY2L25HF	2.5 m	Connecting cable 2.5 m, non halogen, to VDE 0207-24	
ASY2L45HF	4.5 m	Connecting cable 4.5 m, non halogen, to VDE 0207-24	

Туре	Description
AL41	Tamper-proof fitting to prevent dismantling of actuators (for radiator valves only)
AL100	Adapter for retrofitting installed 2W, 3W and 4W valves

# Ordering

When ordering please specify the quantity, product name and type code.

- 1 actuator STP72E with 1.5 m connecting cable and
- 1 adapter AV53

Example 2:

Example 1:

- actuator STP72E/00 without connecting cable,
   connecting cable ASY2L15L, 1.5 m connecting cable with LED operation indication
- 1 adapter AV53

# Delivery

The valves, actuators and accessories are supplied in separate packages.

	Valve type	Description	<b>k<sub>vs</sub></b> [m <sup>3</sup> /h]		PN class	Data sheet
	VVP47	2-port valves	0.254.0		PN 16	N4847
	VXP47	3-port valves				
Standard combination, NC	VMP47	3-port valves with T-bypass	0.252.5			
	2W <sup>1)</sup>	2-port valves	0.62.5			N4846
	3W <sup>1)</sup>	3-port valves	0.64.0			
	4W <sup>1)</sup>	3-port valves with T-bypass	0.62.5			
	VI46, VS4	6 Zone valves <sup>2)</sup>	25	1		N4842
	VDN, VEN, V	UN Radiator valves <sup>2)</sup>	0.091.41		PN 10	N2105, N210
	VPD, VPE	MCV radiator valves <sup>2)</sup>		25483		N2185
	VD1CLC	Small valves <sup>2)</sup>	0.252.6	1		N2103
	Radiator valves 2) (N	A30 x 1.5) from other manufacturers	without adapter,	further ma	nufacturers of	on request:
Combinations, NO	Heimeier		MNG			
	Cazzaniga		<ul> <li>TA-type TI</li> </ul>	BV-C		
	•	30 x 1.5 (from 2001)	<ul> <li>Junkers</li> </ul>	BV-C		
	Honeywell-E		<ul> <li>Beulco ne</li> </ul>			
	For other radiator	valves with type AV <sup>2)</sup> adapters	, see «Type sur	nmary / Ac	cessories»,	page 2
	k <sub>vs</sub> = Nominal flow	v rate of cold water (5 to 30 °C) the	ough the fully o	pened val	/e (H <sub>100</sub> )	
		tial pressure of 100kPa (1bar)				
		ow at a stroke of 0.5 mm				
		t for STE22 and STE72 thermal a ollowing «Application note».	ctuators (adapte	er AL100 r	equired).	
		onowing «Application note».				
echnical note						
IO NC valves	NO valves • Valve is open without actuator (normally open).					
NO, NC valves						
		<ul> <li>Valve stem is extended</li> </ul>		,		
		<ul> <li>Valve stem is extended.</li> <li>Radiator valves like VDN</li> </ul>	VEN VI	•••		PF are
		Radiator valves like VDN	, VEN, V	•••		PE are
		<ul> <li>Radiator valves like VDN usually NO valves.</li> </ul>		UN, VF	PD or V	PE are
	NC valves	<ul> <li>Radiator valves like VDN usually NO valves.</li> <li>Valve is closed without additional values.</li> </ul>		UN, VF	PD or V	PE are
	NC valves	<ul> <li>Radiator valves like VDN usually NO valves.</li> <li>Valve is closed without ac</li> <li>Valve stem is extended.</li> </ul>	tuator (norma	UN, VF	PD or V	PE are
	NC valves	<ul> <li>Radiator valves like VDN usually NO valves.</li> <li>Valve is closed without additional values.</li> </ul>	tuator (norma	UN, VF	PD or V	PE are
/alve and actuator		<ul> <li>Radiator valves like VDN usually NO valves.</li> <li>Valve is closed without ac</li> <li>Valve stem is extended.</li> <li>Small valves like VP47</li> </ul>	tuator (norm	UN, VF ally close / NC valv	PD or Vi d). ves.	PE are
	NC valves	<ul> <li>Radiator valves like VDN usually NO valves.</li> <li>Valve is closed without ac</li> <li>Valve stem is extended.</li> <li>Small valves like VP47</li> <li>STP actuator stem is reference of the stem is refere</li></ul>	tuator (norm	UN, VF ally close / NC valv	PD or Vi d). ves.	PE are
	NO function	<ul> <li>Radiator valves like VDN usually NO valves.</li> <li>Valve is closed without ac</li> <li>Valve stem is extended.</li> <li>Small valves like VP47</li> <li>STP actuator stem is re</li> <li>NO valve is required.</li> </ul>	tuator (norma are usually tracted, whe	UN, VF ally close / NC valv n de-ene	PD or Vi ed). res. rgized.	PE are
		<ul> <li>Radiator valves like VDN usually NO valves.</li> <li>Valve is closed without ac</li> <li>Valve stem is extended.</li> <li>Small valves like VP47</li> <li>STP actuator stem is re</li> <li>NO valve is required.</li> <li>STP actuator stem is re</li> </ul>	tuator (norma are usually tracted, whe	UN, VF ally close / NC valv n de-ene	PD or Vi ed). res. rgized.	PE are
Valve and actuator combinations	NO function	<ul> <li>Radiator valves like VDN usually NO valves.</li> <li>Valve is closed without ac</li> <li>Valve stem is extended.</li> <li>Small valves like VP47</li> <li>STP actuator stem is re</li> <li>NO valve is required.</li> </ul>	tuator (norma are usually tracted, whe	UN, VF ally close / NC valv n de-ene	PD or Vi ed). res. rgized.	PE are
combinations	NO function	<ul> <li>Radiator valves like VDN usually NO valves.</li> <li>Valve is closed without ad Valve stem is extended.</li> <li>Small valves like VP47</li> <li>STP actuator stem is reference.</li> <li>STP actuator stem is reference.</li> <li>NC valve is required.</li> </ul>	etuator (norma are usually etracted, when etracted, when	UN, VF ally close / NC valv n de-ene n de-ene	PD or V d). res. rgized. rgized.	
Note on the NO function	NO function NC function In most applica	<ul> <li>Radiator valves like VDN usually NO valves.</li> <li>Valve is closed without ac</li> <li>Valve stem is extended.</li> <li>Small valves like VP47</li> <li>STP actuator stem is re</li> <li>NO valve is required.</li> <li>STP actuator stem is re</li> <li>NC valve is required.</li> </ul>	tuator (norma are usually tracted, when tracted, when 7 are equip	UN, VF ally close / NC valv n de-ene n de-ene	PD or V od). res. rgized. rgized. STP72E.	thermal
Note on the NO function	NO function NC function In most applicat actuators, i.e. w	<ul> <li>Radiator valves like VDN usually NO valves.</li> <li>Valve is closed without ad Valve stem is extended.</li> <li>Small valves like VP47</li> <li>STP actuator stem is reference.</li> <li>Stromatic stem is reference.</li> <li>Stromatic stem is reference.</li> <li>Stromatic stem is reference.</li> <li>Valve is required.</li> <li>Stromatic stem is reference.</li> </ul>	tuator (norma are usually tracted, when tracted, when 7 are equip	UN, VF ally close / NC valv n de-ene n de-ene	PD or V od). res. rgized. rgized. STP72E.	thermal
Note on the NO function	NO function NC function In most applicat actuators, i.e. w valve is closed.	<ul> <li>Radiator valves like VDN usually NO valves.</li> <li>Valve is closed without ad Valve stem is extended.</li> <li>Small valves like VP47</li> <li>STP actuator stem is researched.</li> </ul>	etuator (norma are usually etracted, when etracted, when 7 are equip ized, the actu	UN, VF ally close / NC valv n de-ene n de-ene oped with	PD or V d). res. rgized. rgized. STP72E. n is retrac	thermal
Note on the NO function	NO function NC function In most applicat actuators, i.e. w valve is closed. If the reverse fu	<ul> <li>Radiator valves like VDN usually NO valves.</li> <li>Valve is closed without ac</li> <li>Valve stem is extended.</li> <li>Small valves like VP47</li> <li>STP actuator stem is re</li> <li>NO valve is required.</li> <li>STP actuator stem is re</li> <li>NC valve is required.</li> <li>tions the small valves VP4</li> <li>then the actuator is de-energe</li> <li>anction is required, STA72E</li> </ul>	etuator (norma are usually etracted, when etracted, when 7 are equip ized, the actu	UN, VF ally close / NC valv n de-ene n de-ene oped with uator ster	PD or V d). res. rgized. rgized. STP72E. n is retract	thermal sted and the ets N4875,
ombinations	NO function NC function In most applicat actuators, i.e. w valve is closed. If the reverse fu N4863) are use	<ul> <li>Radiator valves like VDN usually NO valves.</li> <li>Valve is closed without ad Valve stem is extended.</li> <li>Small valves like VP47</li> <li>STP actuator stem is revealed.</li> <li>STP actuator stem is reference.</li> <li>STP actuator stem is reference.</li> <li>NC valve is required.</li> <li>tions the small valves VP4 when the actuator is de-energy anction is required, STA72E</li> <li>d, i.e. when the actuator is de-energed.</li> </ul>	etuator (norma are usually etracted, when etracted, when 7 are equip ized, the actu	UN, VF ally close / NC valv n de-ene n de-ene oped with uator ster	PD or V d). res. rgized. rgized. STP72E. n is retract	thermal sted and the ets N4875,
ombinations	NO function NC function In most applicat actuators, i.e. w valve is closed. If the reverse fu	<ul> <li>Radiator valves like VDN usually NO valves.</li> <li>Valve is closed without ad Valve stem is extended.</li> <li>Small valves like VP47</li> <li>STP actuator stem is revealed.</li> <li>STP actuator stem is reference.</li> <li>STP actuator stem is reference.</li> <li>NC valve is required.</li> <li>tions the small valves VP4 when the actuator is de-energy anction is required, STA72E</li> <li>d, i.e. when the actuator is de-energed.</li> </ul>	etuator (norma are usually etracted, when etracted, when 7 are equip ized, the actu	UN, VF ally close / NC valv n de-ene n de-ene oped with uator ster	PD or V d). res. rgized. rgized. STP72E. n is retract	thermal sted and the ets N4875,
ombinations	NO function NC function In most applicat actuators, i.e. w valve is closed. If the reverse fu N4863) are use	<ul> <li>Radiator valves like VDN usually NO valves.</li> <li>Valve is closed without ad Valve stem is extended.</li> <li>Small valves like VP47</li> <li>STP actuator stem is revealed.</li> <li>STP actuator stem is reference.</li> <li>STP actuator stem is reference.</li> <li>NC valve is required.</li> <li>tions the small valves VP4 when the actuator is de-energy anction is required, STA72E</li> <li>d, i.e. when the actuator is de-energed.</li> </ul>	etuator (norma are usually etracted, when etracted, when 7 are equip ized, the actu	UN, VF ally close / NC valv n de-ene n de-ene oped with uator ster ctuators the actua	PD or V ed). res. rgized. rgized. STP72E. n is retrac (data shee ator stem i	thermal sted and the ets N4875,
combinations	NO function NC function In most applicat actuators, i.e. w valve is closed. If the reverse fu N4863) are use	<ul> <li>Radiator valves like VDN usually NO valves.</li> <li>Valve is closed without ad Valve stem is extended.</li> <li>Small valves like VP47</li> <li>STP actuator stem is revealed.</li> <li>STP actuator stem is reference.</li> <li>STP actuator stem is reference.</li> <li>NC valve is required.</li> <li>tions the small valves VP4 when the actuator is de-energy anction is required, STA72E</li> <li>d, i.e. when the actuator is de-energed.</li> </ul>	etuator (norma are usually etracted, when etracted, when 7 are equip ized, the actu ., SFA71 a e-energized, STA72E	UN, VF ally close / NC valv n de-ene n de-ene oped with uator ster ctuators the actua	PD or V ed). res. rgized. rgized. STP72E. n is retrac (data shee ator stem i	thermal ted and the ets N4875, is extended
combinations	NO function NC function In most applicat actuators, i.e. w valve is closed. If the reverse fu N4863) are use	<ul> <li>Radiator valves like VDN usually NO valves.</li> <li>Valve is closed without ad Valve stem is extended.</li> <li>Small valves like VP47</li> <li>STP actuator stem is revealed.</li> <li>STP actuator stem is reference.</li> <li>STP actuator stem is reference.</li> <li>NC valve is required.</li> <li>tions the small valves VP4 when the actuator is de-energy anction is required, STA72E</li> <li>d, i.e. when the actuator is de-energed.</li> </ul>	etuator (norma are usually etracted, when etracted, when 7 are equip ized, the actu ., SFA71 a e-energized, STA72E Ac	UN, VF ally close / NC valv n de-ene n de-ene oped with uator ster ctuators the actua	PD or V ed). res. rgized. rgized. STP72E. n is retract (data shee ator stem i STP eenergized	thermal ted and the ets N4875, is extended 72E
combinations	NO function NC function In most applicat actuators, i.e. w valve is closed. If the reverse fu N4863) are use and the valve is	<ul> <li>Radiator valves like VDN usually NO valves.</li> <li>Valve is closed without ad Valve stem is extended.</li> <li>Small valves like VP47</li> <li>STP actuator stem is received.</li> <li>STP actuator stem is refuired.</li> <li>STP actuator stem is refuired.</li> <li>NC valve is required.</li> <li>NC valve is required.</li> <li>tions the small valves VP4</li> <li>then the actuator is de-energy unction is required, STA72E</li> <li>d, i.e. when the actuator is de-energy open.</li> </ul>	etuator (norma are usually etracted, when etracted, when 7 are equip ized, the actu ., SFA71 a e-energized, STA72E	UN, VF ally close / NC valv n de-ene n de-ene oped with uator ster ctuators the actua	PD or V ed). res. rgized. rgized. STP72E. n is retract (data shee ator stem i STP eenergized	thermal ted and the ets N4875, is extended
	NO function NC function In most applicat actuators, i.e. w valve is closed. If the reverse fu N4863) are use and the valve is	<ul> <li>Radiator valves like VDN usually NO valves.</li> <li>Valve is closed without ad Valve stem is extended.</li> <li>Small valves like VP47</li> <li>STP actuator stem is received.</li> <li>STP actuator stem is reference.</li> <li>STP actuator stem is reference.</li> <li>NC valve is required.</li> <li>STP actuator stem is reference.</li> <li>NC valve is required.</li> <li>tions the small valves VP4</li> <li>then the actuator is de-energy inction is required, STA72E</li> <li>d, i.e. when the actuator is despen.</li> <li>VDN, VEN, VUN</li> </ul>	etuator (norma are usually etracted, when etracted, when 7 are equip ized, the actu ., SFA71 a e-energized, STA72E Ac	UN, VF ally close / NC valv n de-ene n de-ene oped with uator ster ctuators the actua	PD or V ed). res. rgized. rgized. STP72E. n is retract (data shee ator stem is stP energized	thermal ted and the ets N4875, is extended 72E
combinations	NO function NC function In most applicat actuators, i.e. w valve is closed. If the reverse fu N4863) are use and the valve is Radiator valves	<ul> <li>Radiator valves like VDN usually NO valves.</li> <li>Valve is closed without ad Valve stem is extended.</li> <li>Small valves like VP47</li> <li>STP actuator stem is revealed.</li> <li>NC valve is required.</li> <li>NC valve is required.</li> <li>tions the small valves VP4</li> <li>when the actuator is de-energy anction is required, STA72E</li> <li>d, i.e. when the actuator is described.</li> <li>VDN, VEN, VUN</li> <li>VPD, VPE</li> </ul>	tuator (norma are usually tracted, when tracted, when 7 are equip ized, the actu ., SFA71 a e-energized, STA72E Ac closed	UN, VF ally close / NC valv n de-ene n de-ene oped with uator ster ctuators the actua	PD or V ad). res. rgized. rgized. STP72E. m is retract (data sheed ator stem is STP renergized op $A \leftrightarrow A$	thermal ted and the ets N4875, is extended <b>72E</b> en <sup>1)</sup>

3/8

. . . . . . . . . . .

#### Technical and mechanical design


	The following description of functions applies to standard applications (valve closed when actuator de-energized) with terminal unit valve types VVP47, VXP47 and VMP47, and types 2W, 3W and 4W			
Function Position indication	When the control signal is applied to the actuator, the temperature of the heating element rises, causing the solid expansion medium to expand. This expansion is converted into a linear movement. The actuator stem is extended and the valve opens When the actuator is de-energized, the actuator stem retracts and the valve is closed by the force of the spring. Die STP72E thermal actuators operate noiseless. The movement and the valve position are indicated by a tactile green bar which moves up and down with the actuator stem.			
	Actuator is de-energized • The actuator stem is retracted • The small valve is closed Actuator has been connected to the power supply for at least three minutes. • The actuator stem is extended • The small valve is open			
Positioning times opening / closing	Positioning signal [%] 1000 1000 1000 1000 1000 1000 1000 1000 1000 1000 1000			

at 20° C ambient temperature

The positioning time depends on the voltage and the ambient temperature. Duty cycle of the control signal is 100 %

# Opening without a positioning signal

With an STP72E... actuator fitted, the valve can be opened to approximately 50% of its stroke without a positioning signal. This enables the hydraulic system to be filled with the medium. For this purpose, the U-pin supplied must be inserted between the actuator housing and the stem as shown in the diagram below.




# Accessories


Note


# Adapter type AV... for third-party valves Note

Adapter types AV51 to AV61 are available for mounting the STP72E... actuators on third-party radiator valves as shown under «Type summary / Accessories», page 2. In these applications, the valves are open when the actuators are de-energized.



#### AL100 adapter





#### Mounting and installation notes

Mounting instructions are printed on the plastic packaging.

The STA72E... actuator and valve are delivered as separate units. They are easy to assemble on site shortly before commissioning:

- Remove the protective cover from the valve body.
- Put the actuator in position and tighten the union nut manually.
- Plug in the connecting cable.
- Only after mounting switch on operating voltage.

Δ Warning

# Do not use pipe wrenches, spanners or similar!

• The plastic packaging can be used as a temporary cover for protection from dust etc.

# Orientation

⚠ Warning	The actuators must be installed only in a position from upright to horizontal. Under no circumstances must the actuator be suspended below the horizontal.
Notes on electrical installation Maintenance	<ul> <li>Installation must be carried out in compliance with local installation regulations.</li> <li>The cable must be connected downwards so that it leads away from the bottom.</li> <li>A means of isolation from the power supply must be provided, for example by connecting an automatic circuit breaker or switch fuse upstream of the control unit.</li> </ul>
	The actuator is maintenance-free.
Repair	Before replacing the connecting cable, disconnect the operating voltage. Opening the actuator can cause it irreparable damage. The actuator cannot be repaired, it must be replaced as a complete unit.
Disposal	The device must not be disposed of as domestic waste. Legislation may demand special handling of certain components, or it may be sensible from an ecological point of view. <b>Current local legislation must be observed</b> .
Warranty	

IP43

450

450

The technical data given for these applications is valid only for valves used in conjunction with the Siemens and third-party actuators listed under «Equipment combinations», page 3.

If the STP72E... actuators are used with other valves, then the user is responsible for ensuring correct functioning and all claims under Siemens Switzerland Ltd / HVAC Products warranty are invalidated.

		STP72E, STP72E/00	
Power supply	Operating voltage	AC 24 V, DC 24 V ±20 % <sup>1)</sup>	
	Frequency	50 / 60 Hz	
	Power consumption at 50 Hz		
	operation	2.5 W	
	on power-up	6 VA	
	Switch-on current (transient)	250 mA	
	Primary fuse	external	
Signal inputs	Positioning signal	2-position, PDM 2)	
	Parallel operation of several actuators	max. 10	
Functional data	Positioning time at 20 °C, 50 Hz	180 s	
	Positioning force	105 N -4/+20 N	
	Nominal stroke	2.5 mm	
	Permissible temperature of medium in	1110 °C	
	the connected valve		
	Actuator de-energized	actuator stem retracted	
	Radiator valves VDN, VEN,	open	
	VUN		
	MCV MiniCombiValves VPD,	open	
	VPE		
	Smal valves VD1CLC	open	
	Small valves VP47	$A \leftrightarrow AB$ closed	
	Zone valves VI46	$AB \leftrightarrow A \text{ open}$	
	Maintenance	no maintenance required	
Electrical connection	Cable length STP72E (standard)	PVC 1.5 m; strands 2 x 0.50 mm <sup>2</sup>	
	STP72E/00	cable ASY2Lrefer accessories page 2	
Mounting	Fixing on valve	Union nut M30 x 1.5; nickel-plated	
	Orientation	Upright to horizontal; do not suspend	
Use		Suitable for indoor use	
Colors	Cover	white, RAL9003	
	Base	light gray , RAL 7035	
	PVC cable	light gray , RAL 7035	
	Non halogen cables	dark gray, RAL 7037	
Norms and standards	Meets requirements for CE marking:		
	EMC directive	2004/108/EC	
	Immunity	EN 61000-6-1 Residential	
	Emission	EN 61000-6-3 Residential	
	Low voltage directive	2006/95/EC	
	Electrical safety	SELV (PELV to IEC 60364-4-41)	
	Protection class	III to EN 60730	
	Contamination level	2 to EN 60730	
	Protection standard		
	Mounted upright ± 45 °	IP 43 to EN 60529	
	Mounted between upright and	IP 41 to EN 60529	
	horizontal		
	Environmental compatibility	ISO 14001 (Environment)	
		ISO 9001 (Quality)	
		SN 36350 (Environmentally compatible products)	
		RL 2002/95/EG (RoHS)	

•

Dimensions / Weight	Dimensions		refer to «Dimensions», page 8		
	Weight	STP72E	0.147 kg		
		STP72E/00	0.105 kg		
		ASY2L15	0.42 kg		
		ASY2L25	0.64 kg		
		ASY2L45	0.105 kg		
Materials	Cover and base		polycarbonate		
	Connecting cable ASY2Lxx		PVC		
	Connecting cable ASY2LxxL		PVC with green LED operation indication		
	Connecting cable ASY2LxxHF		non halogen to VDE 0207-24		
	xx = length in [dm], available		1.5 m; 2.5 m; 4.5 m; strands 2 x 0.50 mm <sup>2</sup>		

Only admissible with extra low voltage (SELV or PELV)
 PDM = pulse duration modulation

General environmental conditions	Operation	Transport	Storage
	EN 60721-3-3	EN 60721-3-2	EN 60721-3-1
Temperature	+5+50 °C	–20+60 °C	+5+50 °C
Temperature for quasi-proportional control	+5+40 °C		
Humidity	585 % r. h.	595 % r. h.	5 95 % r. h.

# **Connecting cable**

STP72E...





Non halogen cables:

black G AC/DC 24 V blue 

### Dimensions

Dimensions in mm





© 2006 - 2008 Siemens Switzerland Ltd

Subject to alteration